



Directions for Use

Insert this element into the housing as described in the user's manual which accompanied the refrigerator at the time of sale. Condition the filtering system by running water through the dispenser for 3 minutes before using. Some models may have a PureSource Filter replacement signal reset button. After changing filter, hold the dispenser button down 3 to 15 seconds to reset the signal. The filter should be changed 6 months from the date of installation.



Operating Specifications

Flow Rate:	.5 gpm/1.89 lpm
Operating Temperature:	33 - 100°F (0.6°C - 38°C)
Min Operating Pressure:	30 psi (207 kPa)
Max Operating Pressure:	100 psi (689 kPa)
Life:	6 months or 300 gallons (1,136 liters)